



# Truck Cover Installation Guide

## STEP #1 APPLY FOAM TAPE TO BASERAILS



STEP 1: Apply foam tape onto the baserails of the truck cap. On some trucks an additional strip may be needed to fill space across the front of the bed.

## STEP #2 SET CAP ON TRUCK



STEP 2: Set the truck cap on the truck.

## STEP #3 ALIGN THE TRUCK CAP ONTO THE BED



STEP 3: Align the truck cap on the bed. Close the gate and the rear door. Then square the cap on the bed.

## STEP #4 TIGHTEN THE CAPS ON THE FRONT CORNERS



STEP 4: Tighten the clamps on the front corners.

## STEP #5A CLAMP DOWN REAR



STEP 5: Clamp down the rear. To do this leave the tailgate down, close the truck cap rear door so that the door channel fits into the channel guides on the doorframe. (The channel guide is the triangle shaped aluminum tab on both sides of the door jam. (See step 5a photo.) This step works best with a helper. If no helper is available you can squeeze the top while standing outside the bed and tighten the clamp with your free hand.

(See additional information below)

## STEP #5B VIEW OF CHANNEL GUIDE



STEP 5 (continued): After both sides are tightened and the door closes into the channels, you may want to bend the channel guides so that the doorframe will slide into the guide easier. (Some people prefer to remove the tab completely after the install is complete.)



## Truck Cover Installation Guide

### STEP #6 ADJUST THE T HANDLE



STEP 6: If necessary. You can adjust the T-handle cam tightness by loosening the 9/16 nut on the T-handle stud. Then loosen the setscrew so the cam will move freely on the stud. Close the rear door, adjust the cam and tighten set screw.